



## INSTALLATION INSTRUCTIONS

### 75-1509

**Dodge**

Dakota V8-5.2L  
Durango V8-5.9L

Parts List							
Qty	Description	Qty	Description	Qty	Description	Qty	Description
1	Intake Tube	1	Throttle Body Gasket	1	5/16" SS Washer	4	SS Pan Head Bolt
1	Intake Box	2	1/4"-20 Hex Head Bolt	1	Steel Bolt	1	Air Filter
1	Intake Lid	6	1/4" Washer	1	4 Bend Bracket		
1	CARB Sticker	2	1/4"-20 Nylock Nut	1	1/4"-20 Set Screw		
1	Instruction Sheet	2	M6 Nylock Nut	4	Sealing Washers		

#### Tools Needed

10mm Socket	Flat head Screwdriver
24mm Socket	Phillips Screwdriver
7/16" Socket	3mm Allen Wrench


1. Turn off engine and disconnect negative battery terminal.



5. Remove the OE air intake tube and plenum



9. Remove the air plenum stud assembly from the throttle body




2. Loosen the hose clamps at the OE air box



6. Unclip the OE air box



10. Install the throttle body gasket per photo 10




3. Disconnect the crank case breather hose



7. Remove the OE panel filter




11. Install the set screw into the tapped hole in the throttle body



4. Loosen the nut that screws the OE air plenum at the throttle body



8. Unbolt and remove the OE air box



12. Locate the S&B cold air bracket



# INSTALLATION INSTRUCTIONS (continued)

13. Place the bracket over the air box studs. Tighten the brackets using the lock nuts provided



14. Install the S&B cold air box and bolt down the box to the bracket. Slide the S&B high performance air filter thru the large hole. Slide the intake tube in to the S&B filter new throttle body studs.



15. Place the S&B cold air intake tube over the throttle body and tighten the threaded stud to screws



16. Tighten the S&B performance filter with the



17. Connect the crank case breather hose



18. Reference photo 18. Assembly should look like photo 18



19. Install the air box lid. Connect the negative battery cable



## Testing & Warranty Info:

1. Engage parking brake and start your engine. To ensure that the system was installed properly, listen for abnormal noises. If an air leak is detected, re-inspect hoses and connections as they may need to be tightened.

2. We recommend that you keep your stock (OEM) intake system in the event that is required in the future.

3. In order to maintain proper warranty, all connections and components must be checked periodically for alignment, re-tightening of all the connections and cleaning. Failure to do so may void your warranty.

4. We recommend that you only use S&B oil and cleaner products to service your filter. Using any other manufacturer's products may void your warranty.

## Smog Certification Note:

The California Air Resource Board (CARB) requires that an E.O. identification label be applied to the vehicle in order to pass a smog check inspection when installing a High Performance Intake Kit.

You must place the E.O. label provided on or near the intake kit after installation so that the smog technician can easily verify the O.E. number during the smog certification process.

RESTORE YOUR HIGH PERFORMANCE FILTER

**PRECISION**  
CLEANING & OILING KIT

S&B'S Precision Cleaning & Oiling Kit allows vehicle owners to properly maintain their high performance air filters by precisely applying the correct amount of oil. The clearly marked bottle and easy-to-use applicator allow the user to measure and apply the proper amount of oil for each application. S&B has conducted extensive testing with the Precision Cleaning Kit to ensure that it can be used on most cotton high performance filters available today.

Part No. 88-0005



Order online today at [www.sbfilters.com](http://www.sbfilters.com) or through your local S&B Distributor

787 S. Wanamaker Ave, Ontario, CA 91761  
(909) 947-0015 Phone • (909) 947-0603 Fax  
[www.sbfilters.com](http://www.sbfilters.com)